Howto open the

GT3RSV2

1. Step: Remove the logo-cap

You must be careful, I used a smaller screwdriver an put a strip of isotape around the metall head.

2. Step: Remove the wheel

There are 3 screws and you need a screwdriver which fits good because the screws have something like locktight on it and you need some pressure during the removing.

Then pull the wheel slowly of. And theres the reason for our extra work, the small casescrew on the front. (I dont put it back in so I dont need to remove the wheel anymore if I want to open the case)

3. Step: Removing the other casescrews

Thats it: